

<< WLAN report >>

```

*****
* Connection : Failed (Error : TS-05)
*****

*****
* Connection Failed.
*****

```

\*\*\* Solution \*\*\*

The Security information(SSID/Network Key) is incorrect.  
 Reconfirm the SSID and security information(Network Key).

- How to confirm wireless security information(SSID/authentication method/encryption method/Network Key)
  - 1) The Default security settings may be provided on a label attached to the WLAN access point/router. Or the manufacturer's name or model no. of the WLAN access point/router may be used as the default security settings.
  - 2) See the documentation provided with your WLAN access point/router for information on how to find the security settings.
- \* If WLAN access point/router is set to not broadcast the SSID, the SSID will not automatically be detected. You will have to manually enter the SSID name.
- \* The Network key may also be described as the Password, Security Key or Encryption Key.

If you do not know the SSID and wireless security settings of your WLAN access point/router or how to change the configuration, see the documentation provided with your WLAN access point/router, ask the manufacturer of your access point/router or ask to your Internet provider or network administrator.

<Configuration>

|                        |                   |
|------------------------|-------------------|
| Network Name (SSID)    | GBA               |
| Hardware Address (MAC) | ac:d5:64:21:1c:2a |
| Communication Mode     | Infrastructure    |
| Authentication Type    | WPA/WPA2-PSK      |
| Encryption             | AES               |
| Network Channel        | -                 |

<Network Search (Ch, Signal, SSID)>

```

1 , 3, InsightAsia_Fibre
6 , 5, GBA-PRINTSERVER
6 , 1, Scaffnet
6 , 1, AirTies4920_F9V4
11, 1, WILLERS
12, 5, GBA

```

TEST PRINT



<< WLAN report >>

\*\*\*\*\*

\* Connection : Failed (Error : TS-05)

\*\*\*\*\*

\*\*\*\*\*

\* Connection Failed.

\*\*\*\*\*

\*\*\* Solution \*\*\*

The Security information(SSID/Network Key) is incorrect.  
Reconfirm the SSID and security information(Network Key).

- How to confirm wireless security information(SSID/authentication method/  
encryption method/Network Key)

- 1) The Default security settings may be provided on a label attached to the WLAN access point/router. Or the manufacturer's name or model no. of the WLAN access point/router may be used as the default security settings.
- 2) See the documentation provided with your WLAN access point/router for information on how to find the security settings.

\* If WLAN access point/router is set to not broadcast the SSID, the SSID will not automatically be detected. You will have to manually enter the SSID name.

\* The Network key may also be described as the Password, Security Key or Encryption Key.

If you do not know the SSID and wireless security settings of your WLAN access point/router or how to change the configuration, see the documentation provided with your WLAN access point/router, ask the manufacturer of your access point/router or ask to your Internet provider or network administrator.

<Configuration>

|                        |                   |
|------------------------|-------------------|
| Network Name (SSID)    | GBA               |
| Hardware Address (MAC) | ac:d5:64:21:1c:2a |
| Communication Mode     | Infrastructure    |
| Authentication Type    | WPA/WPA2-PSK      |
| Encryption             | AES               |
| Network Channel        | -                 |

<Network Search (Ch, Signal, SSID)>

|    |   |   |   |                   |
|----|---|---|---|-------------------|
| 1  | , | 3 | , | InsightAsia_Fibre |
| 6  | , | 5 | , | GBA-PRINTSERVER   |
| 6  | , | 1 | , | Scaffnet          |
| 6  | , | 1 | , | AirTies4920_F9V4  |
| 11 | , | 1 | , | WILLERS           |
| 12 | , | 5 | , | GBA               |